

DST Setting/Module :3511

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



- Upper display
Day of week and Date
- Lower display
Current time

To return to the Timekeeping Mode,
Press © several times.

1.



Seconds

In the Timekeeping mode, hold down
Ⓐ until the second starts to flash.

2.



Press © once.
DST setting screen appears.


3.



ON/OFF

Press Ⓓ to change the DST
Settings. (ON/OFF)

4.



Press (A) to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

