

## Step 1: Steaming

---

If you would rather watch video instruction on how to operate your Baby Food Maker (we hate reading instructions too!), please visit our website:

[www.evlas.com/howto](http://www.evlas.com/howto)

1. Start by filling the water tank (ideally with purified water). Please do not fill past the 'Max' line (approx 7 oz). The Water Tank Cover is securely locked by gently turning
2. Simply tap the Power Button (you will hear a beep and the control panel will light up)
3. Before first use and at regular intervals, we recommend you run the 'sterilize' cycle. Simply press the 'Sterilize Button' ... it will take 10 minutes to complete (the count down timer will show minutes remaining)
4. Refill the water tank up the 'Max' line
5. Prepare your food - we suggest you cut up into 1 inch chunks
6. To remove the stirring cup from the main body of the baby food maker, simply rotate handle clockwise and lift out

7. To open the lid of the stirring cup, hold the handle of the stirring cup in one hand, and then twist the lid clockwise

8. Place your prepared food in the steaming basket (being careful not to overfill)

9. Place the steaming basket securely inside the stirring cup (ensuring handle on the steaming basket is properly aligned).

10. Attach the stirring cup lid by placing on top and rotating anti-clockwise to lock in place

11. To re attach the stirring cup to the main body, ensure the stirring cup handle is aligned with the 'Open' label on base, then simply twist it anti clockwise to lock in place

12. Press the steam button and the steam cycle will start. The default steam time is 15 minutes, this can be adjusted up or down using the time increase or time decrease buttons

13. Once the steaming process is complete you will hear 5 quick beeps

## Step 2: Blending

---

If you would rather watch video instruction on how to operate your Baby Food Maker (we hate reading instructions too!), please visit our website:

[www.evlas.com/howto](http://www.evlas.com/howto)

1. Assuming the steaming process has just completed, start by twisting the stirring cup clockwise to detach it from the main body
2. Open the stirring cup lid (by holding by the handle and then twisting the lid clockwise)
3. Carefully remove the steaming basket, and empty the contents back into the stirring cup. You may wish to add / remove water at this stage depending on the food consistency your little one prefers
4. Reattach the stirring cup lid (by twisting anti-clockwise), and then attach the stirring cup to the main body (by ensuring the stirring cup handle is aligned with the 'Open' label on base, and twisting anti clockwise to lock in place). Double check that the lid remains in the closed position.
5. Press the Auto blend button and the automatic blending cycle will commence. You will hear a beep to confirm the blending cycle is complete (after around 1 minute)

6. Open the lid and your food should be ready for your little one to enjoy. Be sure to check temperature before serving, and allow to naturally cool before freezing

7. If you prefer to manually blend your little ones food (perhaps you want it more chunky), simply press and hold the pulse blend button. When you release the button, the blades will stop

## Step 3: Cleaning & Maintenance

---

If you would rather watch video instruction on how to operate your Baby Food Maker (we hate reading instructions too!), please visit our website:

[www.evlas.com/howto](http://www.evlas.com/howto)

1. We HATE cleaning up ... that's why we designed our Baby Food Maker to self clean! Start by removing any left over puree from the stirring cup and give it a quick rinse under the tap
2. Fill the stirring cup with clean water up to the 'Max Cleaning' line
3. Ensure you attach the spill proof cover and the stirring cup lid, then attach the cup to the main body as before
4. Press the Clean button and the cleaning cycle will commence. You will hear a beep to notify you that the cycle is complete after around 45 seconds
5. Remove excess water and leave unit to dry. Your unit is now clean and ready for next use. Repeat cleaning cycle as necessary
6. We recommend that you also empty, clean and dry the water tank after every use

## Step 4: Sanitizing

---

If you would rather watch video instruction on how to operate your Baby Food Maker (we hate reading instructions too!), please visit our website:

[www.evlas.com/howto](http://www.evlas.com/howto)

1. Before first use and at regular intervals we recommend that you fully sanitize your baby food maker. Don't worry, it's very straightforward ...
2. Start by ensuring the water tank is filled up to the Max line
3. Ensure the stirring cup is correctly attached (please see step 1 above if you do not know how to do this)
4. You can run the sanitize process on the empty unit or you can place small items within the steaming basket (e.g. pacifiers or bottle tops)
5. Power the unit on (simply tap the power button) and press the Sanitize button
6. The Sanitize process lasts around 10 minutes, and will beep 5 times to confirm completion