



Eyeball Network Camera Quick Start Guide

Version 1.0.1




Foreword

General

This manual introduces the functions, installation and operations of the camera.

Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, may result in property damage, data loss, lower performance, or unpredictable result.
 NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

Version	Revision Content	Release Date
V1.0.1	First release.	Aug 2021

Protect Privacy Notice

As the device user or data controller, you might collect personal data of others such as face, fingerprints, car plate number, Email address, phone number, GPS and so on. You need to be in compliance with the local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures include but not limited to: providing clear and visible identification to inform data subject the existence of surveillance area and providing related contact.

About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related regions. For detailed information, see the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.

- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, please refer to our final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation

Important Safeguards and Warnings

Electrical Safety

- All installation and operation should conform to your local electrical safety codes.
- The power source shall conform to the Safety Extra Low Voltage (SELV) standard, and supply power with rated voltage which conforms to Limited power Source requirement according to IEC60950-1. Please note that the power supply requirement is subject to the device label.
- Make sure the power supply is correct before operating the device.
- A readily accessible disconnect device shall be incorporated in the building installation wiring.
- Prevent the power cable from being trampled or pressed, especially the plug, power socket and the junction extruded from the device.

Environment

- Do not aim the device at strong light to focus, such as lamp light and sun light; otherwise it might cause over brightness or light marks, which are not the device malfunction, and affect the longevity of Complementary Metal-Oxide Semiconductor (CMOS).
- Do not place the device in a damp or dusty environment, extremely hot or cold temperatures, or the locations with strong electromagnetic radiation or unstable lighting.
- Keep the device away from any liquid to avoid damage to the internal components.
- Keep the indoor device away from rain or damp to avoid fire or lightning.
- Keep sound ventilation to avoid heat accumulation.
- Transport, use and store the device within the range of allowed humidity and temperature.
- Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.
- Pack the device with standard factory packaging or the equivalent material when transporting the device.
- Install the device in the location where only the professional staff with relevant knowledge of safety guards and warnings can access. The accidental injury might happen to the nonprofessionals who enter the installation area when the device is operating normally.

Operation and Daily Maintenance

- Do not touch the heat dissipation component of the device to avoid scald.
- Carefully follow the instructions in the manual when performing any disassembly operation about the device; otherwise, it might cause water leakage or poor image quality due to unprofessional disassemble. Please contact after-sale service for desiccant replacement if there is condensed fog found on the lens after unpacking or when the desiccant turns green. (Not all models are included with the desiccant).
- It is recommended to use the device together with lightning arrester to improve lightning protection effect.
- It is recommended to ground the device to enhance reliability.

- Do not touch the image sensor (CMOS) directly. Dust and dirt could be removed with air blower, or you can wipe the lens gently with soft cloth that moistened with alcohol.
- Device body can be cleaned with soft dry cloth, which can also be used to remove stubborn stains when moistened with mild detergent. To avoid possible damage on device body coating which could cause performance decrease, do not use volatile solvent such as alcohol, benzene, diluent and so on to clean the device body, nor can strong, abrasive detergent be used.
- Dome cover is an optical component, do not touch or wipe the cover with your hands directly during installation or operation. For removing dust, grease or fingerprints, wipe gently with moisten oil-free cotton with diethyl or moisten soft cloth. You can also air blower to remove dust.



- Please strengthen the protection of network, device data and personal information by adopting measures which include but not limited to using strong password, modifying password regularly, upgrading firmware to the latest version, and isolating computer network. For some device with old firmware versions, the ONVIF password will not be modified automatically along with the modification of the system password, and you need to upgrade the firmware or manually update the ONVIF password.
- Use standard components or accessories provided by manufacturer and make sure the device is installed and maintained by professional engineers.
- The surface of the image sensor should not be exposed to laser beam radiation in an environment where a laser beam device is used.
- Do not provide two or more power supply sources for the device unless otherwise specified. A failure to follow this instruction might cause damage to the device.

Regulatory Information

The regulatory information herein might vary according to the model you purchased.

Some information is only applicable for the country or region where the product is sold.

FCC Information

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC conditions:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

FCC compliance:

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication.

For class A device, these limits are designed to provide reasonable protection against harmful interference in a commercial environment. Operation of this equipment in a

residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- For class B device, these limits are designed to provide reasonable protection against harmful interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.


Table of Contents

Foreword.....	II
Instructions.....	II
Revision History	II
Protect Privacy Notice.....	II
About the Manual	II
Important Safeguards and Warnings.....	IV
Electrical Safety	IV
Environment.....	IV
Operation and Daily Maintenance	IV
Regulatory Information.....	V
FCC Information	V
1. Cable.....	8
2. Network Configuration	9
2.1 Initializing Devices	9
2.2 Modifying IP	11
2.3 Logging in Web Interface.....	12
3. Installation.....	12
3.1. Packing List	12
3.2. Dimension	13
3.3. Installing Device.....	14

1. Cable



- Cable type might vary with different devices, and the actual product shall prevail.
- Waterproof all the cable joints with insulating tape and waterproof tape to avoid short circuit and water damage. For the detailed operation, see the *FAQ Manual*.

Figure 1-1 Cable list



For more information about cable ports, see Table 1-1.

Table 1-1 Cable information


No.	Port Name	Description
1	Ethernet	<ul style="list-style-type: none"> □ Connects to network with network cable. □ Provides power to the device with PoE.  <p>PoE is available on select models.</p>
2	12V DC power input	<p>Inputs 12V DC power. Please be sure to supply power as instructed in the Guide.</p>  <p>Device abnormality or damage could occur if power is not supplied correctly.</p>

2. Network Configuration

The IP address of all the cameras is the same when leaving factory (default IP 192.168.1.250), in order to make the camera get access to the network smoothly, please plan the useable IP segment reasonably according to the actual network environment.

2.1 Initializing Devices

Figure 2-1 Device Search



The screenshot displays the 'IP FINDER' application interface. At the top, it shows '25 Devices found'. Below this, there are filter buttons for 'All', 'IPC', 'SD', 'DVR', 'NVR', and 'Others'. There are also status filters for 'Uninitialized' and 'Initialized', and a dropdown menu set to 'IPv4'. A search bar is present on the right. The main area contains a table with the following data:


NO.	Status	Type	Model	IP	MAC	Version	Operate
1	Initialized	IPC	CP-UNC-TE512L-12T-WDS	172.16.3.13	28:10:5f:42:da:d1	3.100.0000000.0.R	[Edit] [Refresh] [Delete]
2	Initialized	IPC	CP-UNC-TE412L-3T-WDS	172.16.3.157	18:11:c2:33:e0:7a	3.100.0047000.0.R	[Edit] [Refresh] [Delete]
3	Initialized	IPC	CP-UNC-TE512L-12T-WDS	172.16.3.8	28:10:5f:42:da:9d	3.100.0000000.0.R	[Edit] [Refresh] [Delete]
4	Initialized	IPC	CP-UNC-TE512L-12T-WDS	172.16.3.2	28:10:5f:42:da:af	3.100.0000000.0.R	[Edit] [Refresh] [Delete]
5	Uninitialized	IPC	CP-UNC-VE21L3-MDS	192.168.1.250	18:1f:40:02:00:01	3.800.0047000.1.R	[Edit] [Refresh] [Delete]
6	Initialized	IPC	DH-IPC-HFW2448W-S-0-PRO	192.168.1.110	8c:0e:d7:24:48:aa	3.120.0060000.2.R	[Edit] [Refresh] [Delete]
7	Initialized	IPC	CP-UNC-VE21L3-MDS	192.168.1.18	28:10:5f:1e:ed:04	3.800.0047000.0.R	[Edit] [Refresh] [Delete]
8	Initialized	IPC	CP-UNC-TE512L-12T-WDS	172.16.3.8	28:10:5f:42:da:9b	3.100.0000000.0.R	[Edit] [Refresh] [Delete]
9	Initialized	IPC	CP-UNC-VE21L3-MDS	192.168.1.16	14:07:88:44:2f:01	3.800.1783000.0.R	[Edit] [Refresh] [Delete]
10	Initialized	IPC	CP-UNC-VE21L3-MDS-0360	192.168.1.20	14:07:88:75:cd:58	3.820.0047000.1.R	[Edit] [Refresh] [Delete]
11	Initialized	IPC	CP-UNC-VE21L3-MDS-0360	192.168.1.11	14:07:88:75:0a:d7	3.800.0047000.0.R	[Edit] [Refresh] [Delete]
12	Initialized	IPC	CP-UNC-VE21L3-MDS	192.168.1.16	28:10:5f:1e:ed:ee	3.820.0047000.0.R	[Edit] [Refresh] [Delete]

At the bottom of the interface, there are buttons for 'Initialize', 'Modify IP', 'Devices selected', 'Import', 'Export', 'Add', and 'Delete'.

Select one or several uninitialized devices.

Click  Initialize.

Figure 2-2 Set Device Password.



The screenshot shows a 'Device Initialization' window with a dark background. At the top, a red error icon and the text 'device(s) have not been initialized' are displayed. Below this, there are three input fields: 'Username' with the value 'admin', 'New Password', and 'Confirm Password'. The 'New Password' field has a strength indicator below it. Below the password fields, there is a red checkmark icon and the text 'Email Address' followed by an input field and the note '(not password reset)'. At the bottom right, there is a 'Next' button.

Set the initialization parameters for the device.

The **Device Initialization** screen is displayed.



The **Initialization** screen is displayed after initializing is completed.
Click the  success icon () or click the failure icon () for the details.

Figure 2-3 Device Initialized



The screenshot shows an 'Initialization' window with a dark background. At the top, a red error icon and the text 'device(s) have been activated!' are displayed. Below this is a table with the following columns: 'NO.', 'Type', 'Model', 'IP', 'MAC', and 'Version'. There is one row of data with a green checkmark in the 'Type' column.

NO.	Type	Model	IP	MAC	Version
1	✓ IPC	CP-UNC-VBB1ZL4C-VMDS	192.168.1.250	fc:5f:40:6d:a6:d7	2.890.00AT002.0.R


At the bottom right, there is a 'Finish' button.

Click **Finish** to finish initialization.

After the initialization is completed, the status of the devices shows as **Initialized** on the main user interface of the Tool. Meanwhile, the devices appear in other interfaces of the Tool.


2.2 Modifying IP

Figure 2-4 Device Search



Find the device you want to modify IP, and then click the **IP Modification** button. The **Modify IP Address** dialog box is displayed.

Figure 2-5 IP Modification



Select the mode for setting the IP address according to the actual situation. Click **OK** to complete modification.

2.3 Logging in Web Interface

Step 1 Open IE browser, then enter the IP address of the device in the address bar, and then press Enter.


If the setup wizard is displayed, finish the settings as instructed.

Step 2 Enter the user name and password in the login box, and then click **Login**.

Step 3 For first time login, **click Here to Download Plugin**, and then install the plugin as instructed.

The main interface is displayed when the installation is finished.

Figure 2-6 Main interface










3. Installation

3.1. Packing List



- The tool required for the installation such as electric drill is not provided in the packing.
- The operation manual and related tool are contained in the disk or the QR code, and the actual packing shall prevail.

Figure 3-1 Packing List

Network Camera × 1	Manual × 2	CD-ROM/QR Code × 1	Wrench × 1
			
Waterproof Connector × 1	Screw Package × 1	Positioning Map × 1	
			


3.2. Dimension



Following figures are for reference only, and the actual product shall prevail.

(Unit: mm [inch])


Figure 3-2 Dimension



3.3. Installing Device

3.3.1. Installation Direction

Figure 3-3 Installation Direction



3.3.2. Installation Method


Option 1: - Cable going through the side cable tray.

Figure 3-4 Installation Method (option 1)



Option 2: - Cable going through the mounting surface.
Figure 3-5 Installation Method (option 2)






3.3.4. Installing Waterproof Connector (Optional)


This part is needed only when there is waterproof connector come with the device and the device is used outdoor.

Figure 3-6 Installing waterproof connector



3.3.5. Adjusting Lens Angle

Figure 3-7 Adjusting Lens Angles



Thanks for Choosing CP Plus!



Website: - www.cpplusworld.com

Email id: - sales@cpplusworld.com; support@cpplusworld.com

