



KUMI WATCH Gear GT3  
**Instructions Manual**

v1.0

Thank you for choosing KUMI smartwatch. This manual will give you a complete understanding of how to use the equipment. This device is mainly connected to the mobile phone through Bluetooth function, providing a variety of practical functions and services to facilitate your operation of the mobile phone, and has developed many functions for human sports and health.

This equipment is not a medical device, and the measurement data and results are only for reference, not for diagnosis and treatment.

Due to the continuous improvement, optimization and upgrade of the product, the user may expect slight difference between the actual product and the description in this manual.

Based on the principle of continuous improvement and continuous optimization, the company reserves the right to modify and improve any content and product information and functions described in the document without prior notice.

## 1. Packing List



KUMI WATCH  
Gear GT3 x1



Wireless Charging  
Base x1



Manual x1



Protective Film x1

## 2. Basic Parameters

Product Name	KUMI WATCH Gear GT3 Smartwatch
Body Material	Alloy,PC ,Glass
Wristband Material	Silicone+Leather
Wristband Size	22mm

Battery Specification	300mAh Lithium Polymer Battery
Charging Method	Wireless Charging
Charging Time	2-3 hours
Charging Temperature	0-40°C

### 3. Product Introduction




- ① Touch Screen
- ② Digital Bezel
- ③ Digital Crown
- ④ Shortcut Key
- ⑤ Microphone
- ⑥ Speaker
- ⑦ Heart Rate Sensor
- ⑧ Vent Hole

#### 4. Watch Charging and Activation

Align the wireless charging base with the back of the watch and ensure they are properly attached. When the watch screen displays a charging indicator, it means it is charging. Please charge your watch promptly when it indicates low battery

The charging power input of the watch is 5V  $\approx$  1A, so do not use a power adapter supporting higher than 5V for charging

The device is an all-in-one machine, and the back shell and battery are not removable



#### 5. App Download

Search for "KUMI Sports" in Google Play, or search for "KUMI SportsAI" in App Store, or scan the QR code below, and follow the prompts to download and install



App Store : KUMI SportsAI



Google Play : KUMI Sports



## 6. Watch Connection Binding App

Note: Before binding the watch, please ensure that the watch is not connected to another phone. If it is, please unbind it first

Method 1: Enter the app > Devices > Add Device > Select 'Gear GT3' and follow the prompts to complete device binding



Method 2: Enter the APP > Home page > Tap the "... " in the upper right corner > Add Device, select 'Gear GT3' or scan the QR code on the watch's initialization screen, and follow the prompts to complete the device binding



## 7. Operating Instructions

### I. Button Operations

1) Digital Bezel: Rotate to scroll through menus

2) Digital Crown:

Short press: ① Turn on the screen with a short press while the screen is off

② Press the dial interface briefly to access the menu

③ Press briefly on the function interface to return to the previous menu level

Double Press: Double Press in the menu interface to switch the menu view

Long Press: ① Press and hold for 5 seconds to power on in the off state

② In the on state, press and hold any interface to quickly access SOS, siren, restart, and power-off functions

\* This feature is not available during the exercise process

3) Shortcut Key: Short press: Enter the exercise mode

Double Press: Customized by user

Long Press: Customized by user

## II. Touch Operations





## 8. Function Introduction



### APP Market

Manage installed apps on the watch, and more apps can be downloaded and installed through the APP



### AI Watch Face

You can use AI drawing capabilities on the watch to generate a personalized dial



### Local Music

You can upload existing audio files to the watch for playback via the APP



### Voice Memo

The Gear GT3 can be used as a portable recording device for capturing and playing back personal memos



### ChatGPT

A dialogue generator based on the GPT model, it facilitates natural language interaction. Users can communicate with ChatGPT by entering text or speaking, and ChatGPT will generate responses based on the input content



### Smart Memo

The smart reminders from the app can be synchronized and displayed on the watch



### Translator

Set the local and target languages in the function interface. Click the microphone icon and speak the local language that needs to be translated. After clicking to end the speech, it will automatically be translated into the target language. Click the "↔" icon to switch the languages



#### Heart Rate

When entering the heart rate measurement interface, the bottom green light will turn on to start measuring, and it will take approximately 40 seconds to complete the measurement



#### Blood Oxygen

When entering the blood oxygen measurement interface, the bottom green light will turn on to start measuring, and it will take approximately 30 to 60 seconds to complete the measurement



#### Sport

The watch comes with more than 100 types of sports modes, including run and walk, cycling, swimming, outdoor sports, indoor activities, dance movement, Combat sports, and ball games



### Sleep

View the sleep data recorded by the watch for the current day, including deep sleep, light sleep, bedtime, and wake-up time, among other sleep records



### Pressure

Utilize heart rate variability data in conjunction with the corresponding stress calculation model to estimate the user's stress state and level. The watch interface can display the current stress value, average stress value, and stress range. Please open the APP on your phone during the test



### Activity Record

Record the number of daily activities, exercise duration, and step count statistics. You can change the exercise goals and check the progress of the exercise completion



### Phone

You can view the recent call records, contacts on the watch, and make manual dial calls from the watch



### Weather

Once the app obtains location permission from the phone, it can sync the current weather information of the phone's location to the watch. This includes today's weather conditions, temperature, UV intensity, wind gust strength, humidity, as well as the weather forecast for the next six days



### Alarms

In the function interface, click on the "+" to set the reminder time and reminder cycle to complete the setup; to delete an alarm, swipe left on the corresponding alarm reminder task. The watch can add up to 8 alarm tasks



#### **Breathe**

During the breathing exercise, you can choose a training duration of 1 minute, 2 minutes, or 3 minutes. After clicking start, follow the icons to inhale as they enlarge and vibrate, and exhale as they shrink



#### **Remote Camera**

Please enter the APP and go to "Devices" - "Shake to Take Photo". Once you have positioned the phone for the photo, click the screen icon to complete the photo capture



#### **Find Phone**

Tap the function icon to enter the "Find My Phone" feature. At this point, the phone will light up the screen, vibrate, and ring to provide a reminder. Press the digital crown button to exit the "Find My Phone" function



#### Message

Once the watch is connected to the APP, open the relevant information push notifications on the APP side, and the watch will receive the corresponding message push notifications



#### Calendar

Display the current date, month, and day of the week. By tapping on the monthly calendar, you can view the public holidays, traditional Chinese solar terms, and the Chinese lunar calendar information for the month



#### Setting

Personal information, notify, universal, display and brightness, sound and touch, gestures, time setting, battery, password, key definition, secondary screen settings, menu theme, live window, DND Mode, power saving mode, bedsideclock, sleep, sport, health reminder, heart rate, help guide



### Games

Fun Mini-Games



### Timer

In the function interface, the system has preset common durations for timing. Users can tap on the corresponding duration for a quick timer, or tap the "Customize" button to set the time as needed



### Calculator

It can perform calculations for numbers up to 8 digits (inclusive). Calculation results exceeding 8 digits will be displayed using scientific notation. The maximum input value for a single calculation is 8 digits





### Drain

After the watch comes into contact with water, click on the drainage function to use the speaker to emit high-frequency sound waves, which will vibrate and expel the residual water from the speaker holes, preventing issues such as weakened sound or other problems caused by remaining water



### Stopwatch

Tap the "⏸" icon or press the digital crown to start timing,  
Tap the "⏹" icon or press the digital crown to pause timing,  
Tap the "⏴" icon to record the duration,  
Tap the "⏲" icon to reset the timer to zero, and swipe right on the screen to exit the stopwatch feature



### Siren

In case of an emergency, you can tap the siren function, and the watch will emit a piercing alarm to attract the attention of others



#### **Voice Assistant**

In the function interface, tap the voice ball to awaken the phone's voice assistant, and you can then issue voice commands through the watch to the phone and receive feedback from the phone



#### **Business Card Holder**

Save the QR codes of your social media accounts like WeChat, QQ, Facebook, WhatsApp, X, etc., to the watch via the mobile APP. Tap the corresponding icon to display the QR code of the respective account for adding friends



#### **Wallet**

You can save the QR codes for receiving payments from third-party payment tools such as WeChat, Alipay, and PayPal to the watch through the mobile APP. By tapping the corresponding icon, you can display the QR code for receiving payments



#### Respiratory Rate

Respiratory rate is a medical term that describes the number of breaths taken per minute. A single rise and fall of the chest counts as one breath, which includes one inhalation and one exhalation. The number of breaths per minute is referred to as the respiratory rate



#### World Clock

In the function interface, click the "+" to add and display the local time of different countries around the world on the watch for viewing

## 9. Frequently Asked Questions

### The watch does not turn on

- 1) Check whether the power is sufficient, use the charging cable to charge the watch, and the charging voltage shall not be higher than 5V;
- 2) Check whether the watch screen is damaged by external forces, such as accidental drop;
- 3) Check whether the watch has water, damp caused by internal circuit short circuit can not be turned on.

**Bluetooth not connected or unable to connect**

- 1) On the watch face screen, swipe up to access the control center and check if the "📶" icon is in a disconnected state;
- 2) Check whether the Bluetooth of the mobile phone is enabled normally and whether the APP has obtained the location permission;
- 3) Try restarting the device or performing a factory reset

**Why Android phones are easy to disconnect**

The App should be running in the background continuously, however, Android's memory management will force the App to close. To fix this, it is needed to manually disable the phone's power saving mode, or add the App to the system management green background. For specific steps to configure this, please refer to the manual of your phone or contact KUMI customer service

For more frequently asked questions, please check the App [My>FAQ] or send an email to our customer service email [service@kumi.top](mailto:service@kumi.top)

## 10.SAFETY WARNING

Please read all safety information before using this product to ensure safe and proper use.

1. In case of equipment failure or factory reset, if you do not keep the backup file safely, you will not be able to recover the previous data. Be sure to back up all important data stored on the equipment and keep it in a safe place;
2. When using a power-intensive application or using an application on the device for a long time, the device feels hot to the touch, which is normal and does not affect the use or performance of the device;
3. If the touch screen is equipped with protective film or the hands are not clean, or the touch screen reacts slowly and may not work properly, if the touch screen is scratched or damaged, there may be a risk of water ingress and moisture;
4. This product is not suitable for children under the age of 14 to use alone;
5. All packaging materials (such as tape, plastic bags, plastic sheets, labels, binding lines, etc.) and small parts of the machine should not be touched by children under 3 years old to avoid suffocation risk.

Observe the following warnings to prevent personal injury or damage to equipment:

1. Do not allow children or animals to chew or swallow the equipment and accessories;
2. Do not poke eyes, ears or other body parts with the device or put the device in your mouth;
3. Do not store the equipment in an overheated or overcooled environment. It is recommended to use it in an environment with a temperature between -5°C and 40°C;
4. Do not store equipment near or inside heaters, microwave ovens, cooking equipment, or pressure vessels;
5. Do not drop, squeeze, impact or scratch the equipment;
6. Do not use the equipment in thunderstorm weather;
7. Please keep the equipment dry and clean;
8. Please observe all safety warnings and regulations regarding the use of mobile devices while driving;
9. Do not wear or use this product while charging.

## 11.LEGAL STATEMENT

- Copyright © KUMI Technology Co., Ltd. All rights reserved.
- The company has the right to modify any information in this manual at any time without notifying any third party, and does not assume any responsibility to the third party for such modification;
- Without the written consent of the company, any unit or individual shall not extract, copy or use the contents of this manual in any other way, and shall not transmit it in any form;
- This guide is for reference only and does not constitute any form of commitment. Products (including but not limited to color, size screen display, etc.) shall be subject to the actual product;
- Due to the upgrade of software version, the contents introduced in this guide are for reference only. Please refer to the actual product;
- This equipment is not a medical device. The measurement data and results are for reference only and should not be used as the basis for medical diagnosis. If you feel uncomfortable, please consult a medical institution.

## 12.FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,



which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2BGPH-GEARGT3



KUMI Technology Co., Ltd.

Web: [www.kumi.top](http://www.kumi.top)

Mail: [service@kumi.top](mailto:service@kumi.top)

Address: KUMI Technology, Room 405, Block A, United  
Financial Holdings Building, No.1 Shihua Road, Hetao  
Shenzhen-Hong Kong Science and Technology  
Innovation Cooperation Zone, Futian District, Shenzhen

Made in China

